

HBD - Base Drum Heater (up to 150 °C) - Operating Instructions

Safety instructions

1. Read all instructions before using the heater.
2. When not in use unplug the mains lead.
3. Do not immerse the heater in liquids.
4. Do not touch the surface of the heater during operation. After switching off, allow the heater to cool completely before handling.
5. Use the heater only for its intended use, as described in these instructions.
6. Disconnect from the electrical supply before removing terminal cover.
7. The heater must not be used if it is damaged in any way. If the mains lead is damaged, it must be replaced by the manufacturer or a similarly qualified person in order to avoid hazard, using a special flexible cord.
8. The heater should be connected to the electrical supply via a residual current device or other equipment providing protection from electric shock.
9. During operation, vent the drum to avoid building up of internal pressure.



Electrical requirements

Check that the voltage marked on the heater corresponds to the electricity supply that it will be connected to which must be AC (Alternating Current).

The HBD is of double insulated construction so does not require an earth connection. A suitable approved plug for the country in which the heater is being used should be fitted to the mains lead by a suitably qualified person.

Instructions for use

1. The Base Drum Heater HBD is designed to be used for 200L steel drums for the warming of the contents.
2. The heater is not designed for use with plastic drums, as the adjustable temperature is higher than the maximum permitted temperature for plastic drums. We therefore do not assume any warranty for the use of plastic containers on our HBD Base Drum Heaters.
3. Put the drum on the steel plate of the heater. Make sure that the drum is in flush contact with the steel plate.
4. Set the thermostat to the required temperature.
NOTE: The thermostat sensor is positioned to sense the temperature at the junction between heater surface and drum, not the drum contents. Obtaining the ideal temperature of the drum contents must be via experimentation and experience of the material being heated.
5. Plug the heater into the electricity supply.
6. The HBD will begin to heat up and continue until the required temperature set by the thermostat is reached. It will then cycle at this set point until the thermostat setting is changed or the heater is removed from the electricity supply.
7. Switch off and remove the heater from the drum before discharging the contents. This will avoid contaminating the heater from spillages.

HBD - Base Drum Heater (up to 150 °C) - Operating Instructions

Cleaning & storage

Before cleaning the heater always disconnect from the electricity supply. Wipe the jacket and terminal box with a damp cloth. Do not use solvents or scouring agents and never immerse the heater in liquid.

When not in use, the heater can be folded rolled up for storage. For further information on use or service contact the manufacturer or supplier.


Technical data

Max. temperature	150 °C
Outer material	steel
Insulation material	none
Protection class	II
Cable length	2 meters
Type of cable	PVC cable with braided metal sleeve and PVC sheath
Fastening	-
Control	Capillary pipe thermostat
Control range	0 – 150 °C
Heating zones	1
Special sizes possible	no

Power at 230 V	Heating surface size	Control unit size	Total size	Part-No.
900 W	Height 70 mm Ø Top 550 mm Ø Bottom 600 mm	Height 105 mm Length 280 mm	Height 105 mm Length 880 mm Width 600 mm	387N.001

Legend:

- 1) Base
- 2) Heating mat
- 3) Thermal insulation
- 4) Controller & housing
- 5) Control dial
- 6) Access to control dial
- 7) Vision panel
- 8) Cable



Find more information about us and our products on www.freek-fassheizungen.de or www.freek-heaters.com.

No warranty claims can be derived from these user instructions.

Contact

Friedr. Freek GmbH
Sudetenstraße 9
58708 Menden
Tel.: +49 2373 9590 0
Fax.: +49 2373 9590 30

freek-fassheizungen.de



Download our contact details on your smart phone. Just scan the code with your QR-Reader-App.